

THE ULTIMATOLL Q-16S-E

Economy System

**Integrated Home/Office
Telephone Intercom System**

User's Manual

*Congratulations on your purchase of **The Ultimatoll**.*

It means great convenience and comfort for your new or remodeled home, savings and professional image for your existing or future small office, your store or home business. To the hobbyists for themselves, it will surely bring lots of fun.

For your convenience, this manual has been made as comprehensive and repetitive as possible. To fully enjoy your Integrated Home/Office Controller, follow these comprehensive step-by-step instructions.

*To install the Unit, you may either use the instructions from the **Quick Installation Help** guide provided with this manual or the instructions at the beginning of this manual. When using the installation instructions from the manual, please read the **Installation and Programming Sections** completely **before** putting the Unit in operation. Follow these comprehensive step-by-step instructions, which will help you install the Unit quickly, securely and hassle free.*

TABLE OF CONTENTS

1	INSTALLING THE CONTROLLER	11
1.1	INSTALLING THE ULTIMATOLL Q-16S.....	11
1.1.1	<i>Wall Mounting Unit</i>	<i>11</i>
1.1.2	<i>Connecting Ultimatoll Unit to Phone Wirelines</i>	<i>12</i>
1.1.3	<i>How to Install Controller for Multi-Line Applications</i>	<i>12</i>
1.1.4	<i>Installing for Line Sharing with Business Phone System (PBX)</i>	<i>13</i>
1.1.5	<i>Doorphone Installation</i>	<i>13</i>
1.1.6	<i>Doorstrike Installation</i>	<i>14</i>
1.1.7	<i>Music Source Installation</i>	<i>15</i>
1.1.8	<i>Alarm Installation</i>	<i>15</i>
1.2	IMPORTANT FACTS ABOUT YOUR SYSTEM AND YOUR PHONE LINE	16
2	TROUBLESHOOTING THE INSTALLATION	18
2.1	GENERAL TROUBLESHOOTING	18
2.2	TROUBLESHOOTING RING PROBLEMS	19
3	PROGRAMMING THE ULTIMATOLL.....	21
3.1	PRELIMINARY INDICATIONS	21
3.1.1	<i>Changing the Default Password</i>	<i>22</i>
3.1.2	<i>How to Change a Former Password.....</i>	<i>22</i>
3.1.3	<i>Programming the Surveillance Number.....</i>	<i>23</i>
3.1.4	<i>How to Erase the Surveillance Number.....</i>	<i>23</i>
3.1.5	<i>Programming the Doorphone Forwarding Number</i>	<i>23</i>
3.1.6	<i>Examples of Data Strings for Surveillance and Forwarding Numbers</i> <i>24</i>	
3.1.7	<i>Clearing all Programmed Data from Memory.....</i>	<i>24</i>
4	NORMA OPERATION MODE.....	25
4.1	INCOMING EXTERNAL CALLS	25
4.2	PUTTING AN EXTERNAL CALL ON HOLD (CALL PARKING)	25
4.3	HOW TO ANSWER A DOORPHONE CALL	25
4.4	HOW TO PLACE A PHONE CALL.....	26
4.5	HOW TO ACCESS THE DOORPHONE(S).....	26
4.6	HOW TO TAKE A PHONE CALL WHILE ATTENDING TO A DOORPHONE CALL 27	
4.7	HOW TO TAKE A DOORPHONE CALL WHILE ENGAGED IN A PHONE CALL	27
4.8	HOW TO ENABLE OR DISABLE THE ALARM	27
5	ABSENCE MODE	29
5.1	HOW TO PROGRAM THE SURVEILLANCE NUMBER	29

5.2	HOW TO ENABLE THE ALARM FUNCTION	30
5.3	HOW TO ENTER THE ABSENCE MODE.....	30
5.4	HOW TO ENABLE SURVEILLANCE WHILE AT HOME	30
5.5	HOW TO CLEAR THE SURVEILLANCE NUMBER	30
5.6	HOW TO DISABLE THE ALARM IN ABSENCE MODE	31
5.7	HOW TO DISABLE THE ALARM IN NORMAL MODE.....	31
5.8	DOORPHONE CALLS IN ABSENCE MODE	31
5.9	HOW TO CANCEL THE ABSENCE MODE	32
LIST OF FUNCTION CODES.....		33
THE FOLLOWING IS A LIST OF FUNCTION CODES FOR QUICK REFERENCE		33
6	ADDITIONAL INFORMATION.....	34
6.1	IMPORTANT INFORMATION.....	34
6.2	LIMITED 1 YEAR WARRANTY	35
6.3	IMPORTANT SAFETY INSTRUCTIONS.....	36
6.4	CAUTION	37
6.5	BEFORE YOU CALL FOR SERVICE.....	38
6.6	SPECIFICATIONS.....	39